Dual Time- Zone Talking Clock

This EL backlit dual-time-zone with dual-alarm Talking Clock provides these features:

- **Dual LCD Readout Display -** displays time in any two time zones.
- **EL backlight -** lets you see the time in the dark.
- **Time Announcement -** lets you hear the time.
- **Daily Alarm for Home and Local -** lets you have separate alarm for different time zone.
- **Large Liquid Crystal Display -** shows you large easy-to-read digits.
- **Daylight Saving Time.**

BATTERIES

Your clock uses three AAA(UM4) batteries for power (not supplied). For the longest life and best performance, we recommend alkaline batteries.

Follow these steps to install or replace batteries.

1. Slide open the battery compartment cover on the back of the clock.
2. Insert three fresh AAA batteries in the compartment as indicated by the (+) and (-) marked inside. The clock beeps three times.
3. Replace the cover.

If the clock's sound weakens or the display dims, replace the batteries.

SETTING THE TIME, YEAR, MONTH , DATE , TIME ZONE ,

Note: While setting the time and date, if you do not press any key for more than 15 seconds, the clock returns to the current time display.

Setting Home Time

1. Repeatedly press **MODE** until you hear "Home time set, Hour set", the hour digits flash on the display.
2. Repeatedly press (or hold down) **ADJ** to set the correct hour.
3. Press **SET**, to store the hour, and you hear " Minute set" and the minute digits flash.
4. Repeat Steps 2 and 3 to set the minutes, year, month, date, time zone.
5. Repeatedly press **MODE** to return to the time display.

Note on the Time Zone

- Use the attached map to find the time zone of your home location.
- You must select the correct time zone for your Home time, otherwise an erroneous Local time, which is based on your Home time, will result.

Setting Local Time

The Local time is based on the time zone of Home time, so make sure you have selected a correct time zone for your home time.

1. Repeatedly press **MODE** until you hear "Local time set, Time zone set", the time zone digits flash on the display.
2. Repeatedly press (or hold down) **ADJ** to set your desired time zone.
3. Repeatedly press **MODE** to complete setting the time and return to the time display.

LISTENING TO THE TIME ANNOUNCEMENTS

To hear the time, press **TALKING** on top of the clock. The clock announces for example " Local time 10: 25 , home time 9:25 " and the EL lights up.

To disable the time announcement function of **TALKING** button, simply press and hold TALKING for 2 seconds (the unit sounds a beep).
Press and hold TALKING again for two seconds (the unit sounds four beeps) to enable the time announcem ent function.

SWITCHING TIME AND YEAR DISPLAYS

The clock can display time or date. Repeatedly press **TIME/DATE** to switch between time display and date display.

LOCKING THE KEYS

You can lock all the keys function by sliding **LOCK/UNLOCK** to **LOCK**. To unlock, slide **LOCK/UNLOCK** to **UNLOCK**.

SWITCHING 12H AND 24H

1. Repeatedly press **MODE** until the display shows "12H" or "24H".
2. Press **ADJ** to change.
3. Press **MODE** to return to time display mode.

SETTING THE ALARM TIME

The clock lets you set up a daily alarm for Home time and Local time, follow these steps to set the alarm time.

Setting Home Alarm

1. Repeatedly press **MODE** until you hear "Home alarm set, Hour set", the hour digits flash on the display.
2. Repeatedly press (or hold down) **ADJ** to set the correct hour.
3. Press **SET**, to store the hour, and you hear " Minute set" and the minute digits flash.
4. Repeatedly press (or hold down) **ADJ** to set the correct minute.
5. Repeatedly press **MODE** to complete setting the home alarm time set and return to the time display.

Setting Local Alarm

1. Repeatedly press **MODE** until you hear "Local alarm set, Hour set", the hour digits flash on the display.
2. Repeatedly press (or hold down) **ADJ** to set the correct hour.
3. Press **SET**, to store the hour, and you hear " Minute set" and the minute digits flash.
4. Repeatedly press (or hold down) **ADJ** to set the correct minute.
5. Repeatedly press **MODE** to complete setting the home alarm time set and return to the time display.

TURNING THE ALARM ON AND OFF

You can easily turn on and turn off the alarm using the following steps.

1. To turn on the home alarm, repeatedly press **ADJ** until you hear "Home alarm on" and " " appears on the display, and the alarm time displays for 1.5 sec. To turn off the alarm, press **ADJ** again and you hear " Alarm One Off" and " " disappears.
2. To turn on the local alarm, repeatedly press **SET** until you hear "Local alarm on" and " " appears on the display, and the alarm time displays for 1.5 sec. To turn off the alarm, press **SET** again and you hear " Local alarm off" and " " disappears.
3. With the snooze turned on (Snooze ON/OFF sliding switch on the back of the unit is set to ON), at the preset alarm time, the alarm sounds for one minute andturns off automatically. Then the alarm repeats for another 5 times in every 5 minutes. To silence the alarm sound sooner, press **TALKING**.
4. With the snooze function turned off (Snooze ON/OFF is set to OFF), the alarm sounds for one minute and turns off automatically. To silence the alarm sound sooner, press **TALKING**.

TURNING ON/OFF DAYLIGHT SAVING TIME

There are countries that practice daylight saving time to enjoy sunny summer evenings by moving the clock one hour forward in the spring. This clock allows you to have daylight saving time.

Setting Home Daylight Saving Time

1. Repeatedly press **MODE** until you hear "Home time set. Hour set" then repeatedly press **SET until you hear "Daylight saving time set"** and the " " flashes on the display.
2. Repeatedly press **ADJ** to turn on and off the Daylight saving time.
3. Repeatedly press **MODE** to return the time display.

Setting Local Daylight Saving Time

1. Repeatedly press **MODE** until you hear "Local time set , Time zone set " then press **SET**, you hear "Daylight saving time set " and the " " flash on the display.
2. Repeatedly press (or hold down) **ADJ** to turn on and off the Daylight saving time.
3. Repeatedly press **MODE** to complete setting the time and return to the time display.

Asia	
Abadan	3:30
Abu Dhabi	4
Aden	3
Amman	2
Ankara	2
Baghdad	3
Baku	2
Bandar Seri Begawan	8
Bangkok	7
Beirut	2
Bombay	5:30
Calcutta	5:30
Colombo	5:30
Damascus	2
Dhaka	6
Djakarta	7
Guangzhou	8
Hong Kong	8
Macao	8
Shanghai	8
Taibei	8
Hanoi	7
Irkutsk	8
Katmandu	5:30
Kuala Lumpur	8
Islamabad	5
Jerusalem	2
Karachi	5
Hanoi	7
Rawalpindi	5
Kuwait	3
Osaka	9
Kyoto	9
Nagasaki	9
Tokyo	9
Yokohama	9
Manila	8
Mecca	3
New Delhi	5:30
Nikolayevsk-on-Amure	9
Omsk	5
Vladivostok	+10
Phnom Penh	7
Pyongyang	9
Rangoon	6:30
Seoul	9
Singapore	8
Tehran	3:30
Ulan Bator	8

Europe	
Aberdeen	0
Belfast	0
Birmingham	0
Edinburgh	0
Glasgow	0
Leeds	0
Liverpool	0
London	0
Gibraltar	1
Manchester	0
Amsterdam	1
Rotterdam	1
Antwerp	1
Brussels	1
Bucharest	2
Constantsa	2
Athens	2
Belgrade	1
Berlin	1
Bonn	1
Frankfurt	1
Hamburg	1
Leipzig	1
Munich	1
Copenhagen	1
Dublin	0
Gdansk	1
Warsaw	1
Geneva	1
Zurich	1
Genoa	1
Milan	1
Venice	1
Helsinki	2
Istanbul	2
Kiev	3
Odessa	3
Lisbon	0
Madrid	1
Moscow	3
Murmansk	3
St. Peterburg	3
Oslo	1
Paris	1
Marseilles	1
Prague	1
Reykjavik	0
Sofia	2
Stockholm	1
Tirana	1
Vatican	1
Vienna	1

America	
Anchorage	-9
Atlanta	-5
Baltimore	-5
Boston	-5
Chicago	-6
Dallas	-6
Denver	-7
Detroit	-5
Houston	-6
Las Vegas	-8
Los Angeles	-8
Miami	-5
New Orleans	-6
New York	-5
Philadelphia	-5
Pittsburgh	-5
saint Louis	-6
Salt Lake City	-7
San Diego	-8
San Francisco	-8
Seattle	-8
Washington, D.c.	-5
Asuncion	-4
Belem	-3
Brasilia	-3
Ria de janeiro	-3
Bogota	-5
Buenos Aires	-3
Caracas	-4
Churchil	-6
Edmonton	-7
Montreal	-5
Ottawa	-5
Quebec	-5
Toronto	-5
Vancouver	-8
Winnipeg	-6
Colon	-5
Panama	-5
Havana	-5
Kingston	-5
La Paz	-4
Lima	-5
Mexico City	-6
Montevideo	-3
Paramaribo	-3
Port-of-Spain	-4
San Juan	-4
Santiago	-4

Oceania	
Agana	+10
Apia	-11
Auckland	+12
Wellington	+12
Brisbane	+10
Canberra	+10
Fremantle	8
Hobart	+10
Melburne	+10
Perth	8
Sydney	+10
Honolulu	-10
Noumea	+11
Papeete	-10
Port Moresby	+10
Suva	+12
Vila	+11

Africa	
Abidjan	0
Addis Ababa	+3
Alexandria	+2
Cairo	+2
Algiers	+1
Bamako	0
Banghazi	+2
Tripoli	+2
Beira	+2
Maputo	+2
Brazzaville	+1
Cape Town	+2
Durban	+2
Johannesburg	+2
Pretoria	+2
Dakar	0
Dar el Beida	0
Rabat	0
Dar es Salaam	+3
Djibouti	+3
Douala	+1
Gaborone	+2
Kampala	+3
Kano	+1
Lagos	+1
Khartoum	+2
Kinshasa	+1
Pointe-Noire	+1
Las Palmas	0
Luanda	+1
Lusaka	+2
Mogadishu	+3
Mombasa	+3
Nairobi	+3
Monrovia	0
Ndjamena	+1
Niamey	0
Nouakchott	0
Port Louis	+4
Sao Tome	0
Tananarive	+3
Tripoli	+2
Tunis	+1
Windhoek	+2